

How to Use the UpRite® Cover Lifter to Remove Your Hot Tub Cover



1. Unlock the spa straps.



4. When closing the cover, lift the plastic cylinder above the locking piece on the vertical arm.



2. Reach between the hot tub and cover to break the seal between them.



5. Lower the cover in place and lock the safety straps.



3. Fold the cover over and push it upright. The cover will automatically lock open.

Be sure to contact your local Hot Spring® dealer to order your replacement cover once you begin to see signs of wear on your spa cover.